## OVER

## HOW TO SETUP

TentCraft

Peak Flag

TentCraft | MONARCHTENT SYSTEM



TentCraft.com/MONARCH















- Remove peak flag and hardware from the accessory bag.
- Locate the short and long straight hardware poles and insert past rubber washer to secure peak flag pole.
- Locate "L" hardware pole, and slide into the top of the long straight pole to create completed peak flag pole.
- Now, locate your peak flag and slide the pole through the flag pocket starting from the top of the flag.
- On the top of your peak flag, fold the Velcro flap over the top horizontal pole to secure flag onto the hardware.
- To attach the peak flag, first make sure tent is fully collapsed, open peak cap and slide peak flag pole into peak hole.
- Expand the pop-up tent frame with the peak flag installed.