

TEARDROP FLAG

SETUP INSTRUCTIONS





THANK YOU FOR YOUR PURCHASE!

If you have questions about installation, maintenance, or take down, please call us at (800)426-9496. Our goal is that you are completely satisfied with our products. Please read this installation manual carefully and follow all instructions contained herein. Please note that the installer is responsible for the site selection, installation and use. Do not erect during inclement weather and follow all safety procedures during the installation and take down process.

Please contact all utility companies for underground services. In many states, the utilities work together and have formed a Utility Locating Service. It is your responsibility to locate all the underground services, including speaking to the owner about irrigation, pool and other special services that they may have installed. Also, please note that special precautions should be taken such that any overhead powerlines are duly noted and avoided during the tent erection process.



TentCraft Inc in no way represents the estimated holding power to be true in all cases. It is an estimate, and as such, does not imply that the figures are sufficient to hold any flag securely in windy or adverse weather conditions. The flag installer accepts sole responsibility for the safe installation, teardown, and maintenance of any flag. TentCraft does not represent in any way that the materials provided with the purchase of the flag are sufficient enough to hold it up in windy or adverse weather conditions. There is no way for TentCraft to know the site conditions or the weather conditions at the event. This leaves us unable to recommend the adequate amount of holding power needed to hold the flag safely in position. Furthermore, we are not responsible for the methods which the installer uses to erect the flag or anchor it in position. Installers MUST be empowered to deem the flag unsafe for occupancy if/when the weather becomes unstable.



Step 1



Remove the two cross base arms from the black travel case. Place the cross base arm with the indent on the bottom and place the second cross base arm into the indent, on top of the first arm.

Step 2



Align the holes in the middle of both cross base arms and insert the flag spindles into the hole from the top. Twist the spindle until it securely holds the two arms together.

**Additional Step for Water Bag Base: Remove the cap and fill the bag with water. Tighten cap and place the water base over the cross base, inserting the spindle through the opening in the water base **

Step 3



Place the cross base on the ground, spindle directed upward. Remove flag parts from the black travel case.

** Set aside the straight pole with 90-degree attachment – this is used for rectangular flags **

Step 4



Connect the three flagpole pieces from thinnest to thickest, forming a single flagpole.



Step 5



While holding the flag, locate the opening in the spine of the flag located near the bottom loop holding the black elastic cording.

Slide the thinnest end of the flagpole into the flag, feeding the flag down the pole until it reaches its full height.

Step 6



Pull the black elastic cording down and secure it beneath the hook located at the base of the flagpole.

Step 7



After the flag is installed on the pole, place the bottom end of the pole onto the spindle located in the middle of the cross base.