

# **GY3E | SUN SHADE** SETUP INSTRUCTIONS



## THANK YOU FOR YOUR PURCHASE!

If you have questions about installation, maintenance, or take down, please call us at (800)426-9496. Our goal is that you are completely satisfied with our products. Please read this installation manual carefully and follow all instructions contained herein. Please note that the installer is responsible for the site selection, installation and use. Do not erect during inclement weather and follow all safety procedures during the installation and take down process.

Please contact all utility companies for underground services. In many states, the utilities work together and have formed a Utility Locating Service. It is your responsibility to locate all the underground services, including speaking to the owner about irrigation, pool and other special services that they may have installed. Also, please note that special precautions should be taken such that any overhead powerlines are duly noted and avoided during the tent erection process.



TentCraft Inc in no way represents the estimated holding power to be true in all cases. It is an estimate, and as such, does not imply that the figures are sufficient to hold any tent securely in windy or adverse weather conditions. The tent installer accepts sole responsibility for the safe installation, teardown, and maintenance of any tent. TentCraft does not represent in any way that the materials provided with the purchase of the tent are sufficient enough to hold it up in windy or adverse weather conditions. There is no way for TentCraft to know the site conditions or the weather conditions at the event. This leaves us unable to recommend the adequate amount of holding power needed to hold the tent safely in position. Furthermore, we are not responsible for the methods which the installer uses to erect the tent or anchor it in position. Installers MUST be empowered to deem the tent unsafe for occupancy if/when the weather becomes unstable.

## GY3E SUN SHADE

#### Step 1



Remove the sunshade and poles from the carrying bag. The poles are located inside a Velcro pocket on the inside of the carrying bag.

#### Step 2



Locate the six poles with blue tips and assemble them into three individual poles. The two longer sections connect to create the longest pole and the four shorter sections connect to create two shorter poles.

#### Step 3



Next, take the remainder of the poles and insert the seven pieces into one another to create the longest, front pole.

#### Step 4



Lay the sunshade out on the ground, right side up. (The three black pockets will be facing up.)

## G GY3E SUN SHADE

#### Step 5



Insert the two shorter blue tipped poles into the two shorter pockets on either side of the middle pocket. Close the Velcro tab at the end of the pocket to hold the pole in place.

#### Step 6



Repeat this step using the longest of the blue tipped poles and inserting it into the middle black pocket. Close the Velcro tab at the end of the pocket to hold the pole in place.

#### Step 7



Flip the sunshade over.

#### Step 8



Slip the rubber end of the front pole into the pocket on the edge of the sunshade and Velcro the pocket closed. Repeat on the opposite side.

## G GY3E SUN SHADE

#### Step 9



The pole will lie in a pocket created by the zipper. Zip this closed to attach the pole to the sunshade.

#### Step 10



Once all poles have been inserted, locate the zipper that runs along the full length of the sunshade. Find the zipper pull and ensure that it is at the beginning of the zipper.

#### Step 11



Attach the zipper pull on the sunshade to the beginning of the zipper found on the tent. The tent zipper will be located between the bladder and the roof material. It may be necessary to pull back the roof material to reveal the zipper – as it can be quite taut against the bladder.

#### Step 12



Zip the sunshade in completely along the curve of the tent opening.

## GY3E SUN SHADE

#### Step 13



Once zipped, run the Velcro straps on the bottom of the sunshade through the metal brackets found on both legs of the tent.