

LED LIGHT KIT

SETUP INSTRUCTIONS



THANK YOU FOR YOUR PURCHASE!

If you have questions about installation, maintenance, or take down, please call us at (800)426-9496. Our goal is that you are completely satisfied with our products. Please read this installation manual carefully and follow all instructions contained herein. Please note that the installer is responsible for the site selection, installation and use. Do not erect during inclement weather and follow all safety procedures during the installation and take down process.

Please contact all utility companies for underground services. In many states, the utilities work together and have formed a Utility Locating Service. It is your responsibility to locate all the underground services, including speaking to the owner about irrigation, pool and other special services that they may have installed. Also, please note that special precautions should be taken such that any overhead powerlines are duly noted and avoided during the tent erection process.



TentCraft Inc in no way represents the estimated holding power to be true in all cases. It is an estimate, and as such, does not imply that the figures are sufficient to hold any tent securely in windy or adverse weather conditions. The tent installer accepts sole responsibility for the safe installation, teardown, and maintenance of any tent. TentCraft does not represent in any way that the materials provided with the purchase of the tent are sufficient enough to hold it up in windy or adverse weather conditions. There is no way for TentCraft to know the site conditions or the weather conditions at the event to be able to recommend the adequate amount of holding power needed to hold the tent safely in position. Furthermore, we are not responsible for the methods which the installer uses to erect the tent or anchor it in position. Installers **MUST** be empowered to deem the tent unsafe for occupancy if/when the weather becomes unstable. For further recommendations on determining necessary staking values, please consult the IFAI Procedural Handbook for the Safe Installation and Maintenance of Tentage and the IFAI's Pullout Capacity of Tent Stakes. These resources are available from the IFAI Tent Rental Division.

Step 1




Set up your MASTERTENT according to the instructions. STOP after the canopy is extended. DO NOT raise the canopy to its final height.

Step 2



Remove all equipment from MASTERTENT light kit bag by undoing all velcro straps to release light bars and cords.

Step 3




Arrange the black cord connector so it lays flush against the bottom of the center peak pole. Connect each LED light band to desired frame tent scissor piece using the clear connector brackets. LED light bands can attach to frame tent beams in whatever direction you desire (shining up or down).

NOTE: Make sure the LED light strip containing the attached power cord is positioned near the back of the tent, as you'll want to slip the power cord behind the tent for easy electric access.




Step 4



After positioning all four LED light strips in their desired locations, run the spiral power cord along the scissor piece to the outside frame. Feed the cord through the opening in the scissor piece joint and run to the frame corner of your choosing.

Step 5



Using the spare clear connector brackets, attach the power cord to the back corner of the tent frame.

Step 6



Attach the power cord plug and remainder of power cord by twisting the power cord socket into the LED light band cord socket.

Step 7



Plug in power cord to electric outlet.

Step 8



Use the dial located on the LED light band cord to turn the lights on and off and to adjust brightness to the desired level.

Continue with setup of the MASTERTENT according to instructions.