



6 Legs

*If a 20' Full Wall has been purchased, please follow the steps for a Back Left Wall and ignore the Back Right Wall instructions to ensure correct wrapping.

The Back Left Wall:

- This wall will always wrap first onto the tent.
- If this is a Full Wall- the Velcro along the top of the wall will attach to the Velcro on the Inside of the Valances.
- If this is a Half Wall- the Keder along the top of the wall will slide into the Keder Track on your Half Wall Bar or Counter Hardware.
- The Flaps on the Left and Right sides of the wall will wrap around the tent legs. The Velcro on the flap will wrap and adjoin with the Velcro on the wall.

The Back Right Wall:

- This wall will wrap on second.
- If this is a Full Wall- the Velcro along the top of the wall will attach to the Velcro on the Inside of the Valances.
- If this is a Half Wall- the Keder along the top of the wall will slide into the Keder Track on your Half Wall Bar or Counter Hardware.
- The Flap toward the Center Back Leg of the tent will adjoin to the Velcro on the Outside of the Back Left Wall.
- The Flap toward the Right Side of the tent will wrap around the tent leg and adjoin to the Velcro on the Inside of this wall.



6 Legs (cont.)

The Left Wall:

- This will be the third wall to wrap onto the tent.
- If this is a Full Wall- the Velcro along the top of the wall will attach to the Velcro on the Inside of the Valances.
- If this is a Half Wall- the Keder along the top of the wall will slide into the Keder Track on your Half Wall Bar or Counter Hardware.
- The Flap toward the Front of the tent will wrap around the tent leg. The Velcro on the flap will wrap around and adjoin with the Velcro on the Wall.
- The Flap toward the Back of the tent will wrap around the corner and adjoin to the Velcro on the Outside of the back wall.

The Right Wall:

- This wall will be the fourth wall to wrap onto the tent.
- If this is a Full Wall- the Velcro along the top of the wall will attach to the Velcro on the Inside of the Valances.
- If this is a Half Wall- the Keder along the top of the wall will slide into the Keder Track on your Half Wall Bar or Counter Hardware.
- The Flap toward the Front of the tent will wrap around the tent leg. The Velcro on the flap will wrap around and adjoin with the Velcro on the Wall.
- The Flap toward the Back of the tent will wrap around the corner and adjoin to the Velcro on the Outside of the back wall.

The Front Left Wall:

- This will be the fifth wall to wrap onto the tent.
- If this is a Full Wall- the Velcro along the top of the wall will attach to the Velcro on the Inside of the Valances.
- If this is a Half Wall- the Keder along the top of the wall will slide into the Keder Track on your Half Wall Bar or Counter Hardware.
- The Flap toward the Left Side of the tent will wrap back around the tent leg and adjoin to the Velcro on the Outside of the Left Wall.
- The Flap toward the Center Front Leg will wrap around the tent leg and adjoin to the Velcro on this wall.



6 Legs (cont.)

The Front Right Wall:

- This will be the last wall to wrap onto the tent.
- If this is a Full Wall- the Velcro along the top of the wall will attach to the Velcro on the Inside of the Valances.
- If this is a Half Wall- the Keder along the top of the wall will slide into the Keder Track on your Half Wall Bar or Counter Hardware.
- The Flap on toward the Center Front Leg will adjoin to the Velcro on the Outside of the Front Left Wall.
- The Flap toward the Right side of the tent will wrap around the tent leg and adjoin to the Velcro on the Outside of the Right Wall.